Review: CUMedVision2 / DCAN—Winner of 2015 MICCAI Gland Segmentation Challenge Contest (Biomedical Image Segmentation)




his time, CUMedVision2, also known as DCAN (Deep Contour-Aware Network), by CUHK, is reviewed. In this paper, an intermediate contour label is also used to assist the convergence while training, which is one important concept from this paper. Finally, CUMedVision2 has won the 2015 MICCAI Gland Segmentation Challenge Contest. This is a 2016 CVPR paper with more than 100 citations while I was writing this story. (SH Tsang @ Medium)

The Ranking:

https://warwick.ac.uk/fac/sci/dcs/research/tia/glascontest/results/

You may ask: "Is it too narrow to read about biomedical Image Segmentation? I am not working in this field, Is it not so useful for me?"

However, we may learn the techniques of it, and apply it to different industries. Say for example, quality control/automatic inspection/automatic robotics during construction/fabrication/manufacturing process. These activities involve quantitative diagnosis. If we can make it automatic, cost can be saved with even higher accuracy.




Segmentation by Experts

. . .

- 1. Brief Review of CUMedVision1
- 2. CUMedVision2 Network Architecture
- 3. Some Other Details
- 4. Results


. .

1. Brief Review of CUMedVision1



- 1. As in the figure above, first, we have an input image from the left.
- 2. Then the input image goes through the **down-sampling path** with convolutional and max pooling layers. This path aims at classifying the semantical meaning based on the high level abstract information.
- 3. At certain layers before pooling, the feature maps will go through unsampling path with convolutional and deconvolutional layers. This path is to reconstruct the fine details such as boundaries. Backwards strided convolution is used for upsampling. And we can obtain the results at C1, C2 and C3.
- 4. Next, they are added together, and this fuse map will have the softmax.
- 5. And post-processing is done on the segmentation result using the contour.

2. CUMedVision2 Network Architecture



CUMedVision2

- 1. In CUMedVision2, after going through the conv and pooling, the upper upsampling path is actually the CUMedVision1 network to obtain the segmentation map, *po*.
- 2. And the lower path is the new upsampling path which is similar to the upper path. But instead, the probability map is the contour map, *pc*. This contour map is marked by experts. By adding this intermediate labels in the network, we can drive the weights within the network to have more focus on the boundaries/separation among glands.

This is important because there are many touching glands in the image. IF they are classified into one gland, accuracy will be dropped largely.

3. After obtaining po and pc, we can obtain the m(x), which is the final result according to the following rule:

$$m(x) = \begin{cases} 1 & \text{if } p_o(x; W_o, W_s) \ge t_o \text{ and } p_c(x; W_c, W_s) < t_c \\ 0 & \text{otherwise} \end{cases}$$

where to and tc are thresholds and are set to 0.5 empirically.

. . .

3. Some Other Details

3.1 Loss Function

$$\mathcal{L}_{\text{total}}(x;\theta) = \lambda \psi(\theta) - \sum_{x \in \mathcal{X}} \log p_o(x, \ell_o(x); W_o, W_s)$$
$$- \sum_{x \in \mathcal{X}} \log p_c(x, \ell_c(x); W_c, W_s)$$


The first term: L2 regularization to reduce overfitting.

The second and third terms: the log losses of probability map *po* and *pc*.

3.2 Training

The downsampling path is initialized by DeepLab which is trained by PASCAL VOC dataset. Others are initialized by Gaussian. Fine-tuning is done for the whole network.

3.3 Testing



Overlap-tile strategy

Overlap-tile strategy is used for testing, which means that the segmentation is done part by part for the whole image when the image is too large.

And there are **post-processing steps** which including **smoothing** with a disk filter (radius 3), **filling holes** and **removing small areas** are performed on the fused segmentation results. Finally, each connected component is labeled with a unique value for representing one segmented gland.

4. Results

Three metrics: **F1 score**, **Object-Level Dice index**, and **Hausdorff distance** are measured.

4.1 F1 Score

A score measured by precision P and recall R.

$$F1 = \frac{2PR}{P+R}, \ P = \frac{N_{tp}}{N_{tp} + N_{fp}}, \ R = \frac{N_{tp}}{N_{tp} + N_{fn}}$$

where Ntp, Nfp and Nfn are number of true positive, false positive and false negative respectively. **More than 50% overlap is defined as true positive**. It is just like object detection problem.

4.2 Object-Level Dice index

$$D(G, S) = 2(|G \cap S|)/(|G| + |S|)$$

where a set of pixels G annotated as a ground truth object and a set of pixels S segmented as a gland object. And:

$$D_{\text{object}}(G, S) = \frac{1}{2} \left[\sum_{i=1}^{n_S} \omega_i D(G_i, S_i) + \sum_{j=1}^{n_G} \tilde{\omega}_j D(\tilde{G}_j, \tilde{S}_j) \right]$$


where Si denotes the ith segmented object, Gi denotes a ground truth object that maximally overlaps Si, ~Gj denotes the jth ground truth object, ~ Sj denotes a segmented object that maximally overlaps ~Gj, nS and nG are the total number of segmented objects and ground truth objects, respectively.

Thus, This object-level Dice index is an important metric for **segmentation**.

4.3 Hausdorff distance

It is used for measuring the **shape similarity**:

$$H(G,S) = \max \{ \sup_{x \in G} \inf_{y \in S} ||x - y||, \sup_{y \in S} \inf_{x \in G} ||x - y|| \}$$



Hausdorff distance conceptual diagram

Thus, Hausdorff distance is to get the maximum distance (defined as above) between two shapes G and S in the equation (or X and Y in the figure). **Object-Level Hausdorff distance** is used just like the object-level Dice index as shown above.

Below is the results for the above 3 metrics:

F1 Score Dice index Hausdorff distance Method Method Part A Part B Method Part A Part B Part B Part A CUMedVision2 0.7158 CUMedVision2 0.8974 0.7810 57.0932 148.4630 Freiburg2 [30] ExB3 CUMedVision1 0.8958 0.8680 0.7191 0.7692 ExB1 0.8823 0.7860 Freiburg1 [30] CUMedVision2 57.1938 45.4182 146.6065 160.3469 ExB3 0.8860 0.7647 ExB1 ExB2 0.8912 0.7027 Freiburg2 [30] 0.7856 ExB1 57.4126 145.5748 0.8924 0.6857 187.4420 CUMedVision1 0.8666 0.8001 ExB2 54.7853 Freiburg2 [30] CVIP Dundee Freiburg1 [30] CVML 0.8702 0.6952 ExB2 0.8844 57.3500 159.8730 0.7542 ExB3 0.6328 0.6047 0.5408 0.4790 Freiburg1 [30] CVIP Dundee LIB CUMedVision1 CVIP Dundee LIB 0.8633 0.8745 0.7832 74.5955 58.3386 153.6457 209.0483 0.8340 0.7152 0.8698 0.6521 0.5431 0.8012 0.6166 101.1668 190.4467 Ching-Wei Wang l CVML CVML 0.6444 0.6543 155.4326 176.2439


MICCAI 2015 Results

Part A is benign (normal) glands while Part B is malignant (abnormal) glands. CUMedVision2 has got the rank 1 at F1 score, Dice index, and Hausdorff distance (Part A).


Method	Ranking score						C	Time I monthly a
	F1 A	F1 B	Dice A	Dice B	Hausdorff A	Hausdorff B	Sum score	Final ranking
CUMedVision2	1	3	1	5	1	6	17	1
ExB1	4	4	4	2	6	1	21	2
ExB3	2	2	2	6	5	5	22	3
Freiburg2 [30]	5	5	5	3	3	3	24	4
CUMedVision1	6	1	8	1	8	4	28	5
ExB2	3	6	3	7	2	8	29	6
Freiburg1 [30]	8	8	6	4	4	2	32	7
CVIP	7	7	7	8	7	10	46	8
CVML	10	9	11	9	11	7	57	9
LIB	9	16	9	12	9	9	64	10

Sum Score and Final Ranking

Based on all results, **CUMedVision2 won the MICCAI 2015 gland segmentation challenge contest.** Some visualized results:



Part A Results (Top: Input Image, Middle: No Contour Labels, Bottom: Have Contour Labels)



Part B Results (Top: Input Image, Middle: No Contour Labels, Bottom: Have Contour Labels)

. . .

If we got something want to segment but difficult to segment, some intermediate labels, which involve in the backpropagation, might help to segment. The downside is that we need human power to perform the labeling for the intermediate contour labels. But if human power is not a problem, this is one of the solutions to improve the segmentation accuracy.

. . .

References

 [2016 CVPR] [CUMedVision2 / DCAN]
DCAN: Deep Contour-Aware Networks for Accurate Gland Segmentation

My Reviews

[CUMedVision1] [FCN]